



**Tellurian<sup>®</sup>  
Technologies, Inc.**  
1801 Hicks Rd. Suite A Rolling Meadows, IL 60008  
PH: 847-934-4141 FAX: 847-934-4175  
www.telluriantech.com

**Understanding dB, dBc, and dBm**  
**By**  
**Robert Kinsman**  
**Tellurian Technologies, Inc.**

The term dB and its derivatives dBc and dBm are widely used in the specification and measurement of electronic circuits, particularly crystals, oscillators, and filters. The term dB defines a mathematical relationship that is used to compress large ranges of numbers into a more convenient format. The dB is based on a logarithmic scale and to understand its nature it is necessary to have a basic understanding of logarithms.

The common logarithm ( $\log_{10}$  or simply log) is based on multipliers of the number 10. Other logarithmic scales can be derived from any base number. To grasp the concept of the relationship it is convenient to use a chart as shown here:

<b>Number</b>	<b><math>\log_{10}</math></b>
1	0
10	1
100	2
1000	3
1000000	6

For numbers less than one the logarithm is negative:

<b>Number</b>	<b><math>\log_{10}</math></b>
1/10	-1
1/100	-2

The logarithm of a number is equal to the exponent of the multiples of 10 required to generate the number.

For example:

<b>Number</b>	<b><math>\log_{10}</math></b>
$10 = 10^1$	1
$100 = 10 \times 10 = 10^2$	2
$10,000 = 10 \times 10 \times 10 \times 10 = 10^4$	4



**Tellurian<sup>®</sup>  
Technologies, Inc.**  
1801 Hicks Rd. Suite A Rolling Meadows, IL 60008  
PH: 847-934-4141 FAX: 847-934-4175  
www.telluriantech.com

For numbers that are not exact multiples of 10 the logarithm will be some fraction that will fall between the numbers shown in the table.


For example:

$$\log 7 = 0.8451$$

$$\log 250 = 2.3979$$

Before the advent of the hand held calculator, values for logarithms were printed in books (log tables) and their use required a considerable amount of arithmetic manipulation. Now with calculators readily available, logarithms can be easily looked up and used with the touch of a few buttons. Logarithmic scales are frequently used in graphs where a wide range of numbers are needed. The logarithmic scale expands the smaller numbers and compresses the larger numbers.

An example of the use in graphs is shown here where the x-axis uses a linear scale and the y-axis uses a logarithmic scale:





**Tellurian<sup>®</sup>  
Technologies, Inc.**

1801 Hicks Rd. Suite A Rolling Meadows, IL 60008  
PH: 847-934-4141 FAX: 847-934-4175  
www.telluriantech.com

The decibel, based on logarithmic relationships, is widely used in electronic measurement and specifications.

The definition of the decibel as listed in the handbook *Reference Data for Radio Engineers* is:

“The decibel, abbreviated dB, is a unit used to express the ratio between two amounts of power,  $P_1$  and  $P_2$ , existing at two points. By definition:


$$\text{number of dB} = 10 \log_{10} (P_1/P_2)$$

It is also used to express voltage and current ratios:

$$\text{number of dB} = 20 \log_{10} (V_1/V_2) = 20 \log_{10} (I_1/I_2)$$

It can be shown that all of these expressions represent equal conditions because power is proportional to the square of voltage or current. However, in using the unit dB, it is essential to define whether it is a power ratio or voltage/current ratio.


The decibel is normally used to define the frequency response of filters and also to describe the gain characteristics of amplifiers. In filters the frequency response is determined as follows:





**Tellurian<sup>®</sup>  
Technologies, Inc.**  
1801 Hicks Rd. Suite A Rolling Meadows, IL 60008  
PH: 847-934-4141 FAX: 847-934-4175  
www.telluriantech.com

### Frequency Response



The voltage  $V_1$  is defined as the level at the point of minimum loss, and  $V_2$  is the voltage as a function of frequency. Because values for  $V_2$  will be equal to or less than  $V_1$  the scale will be negative.


The decibel is also used to define the level of harmonic and spurious outputs in oscillators and VCO's. This is illustrated in the following diagram:



**Tellurian<sup>®</sup>  
Technologies, Inc.**

1801 Hicks Rd. Suite A Rolling Meadows, IL 60008  
PH: 847-934-4141 FAX: 847-934-4175  
www.telluriantech.com

## Harmonic and Spurious Signals in an Oscillator



Some examples of dB levels that are frequently specified are:

$$-3\text{dB} = \frac{1}{2} \text{ power}$$

$$-6\text{dB} = \frac{1}{2} \text{ voltage}$$

$$-40\text{dB} = \frac{1}{100} \text{ voltage}$$


$$-60\text{dB} = \frac{1}{1000} \text{ voltage}$$

To get a feel for the extremely low power levels specified in sideband noise for example:

$$-100\text{dBc} = \frac{1}{1,000,000,000} \text{ power}$$

The term dBc stands for decibels below the carrier and is used in defining the sideband noise properties of oscillators. This is illustrated in the figure below:

### Oscillator Sideband Noise Spectrum



In this application the expression is a power ratio comparing the power in the carrier frequency of the oscillator to the power of the sideband noise contained in a one Hertz bandwidth. The scale of the y-axis will be in dBc.

The unit dBm was commonly used in the telephone industry as a reference power level and is defined as:

$$0 \text{ dBm} = 1 \text{ mW of signal power}$$

With this definition,

$$\begin{aligned} 10 \text{ dBm} &= 10 \text{ mW} \\ 20 \text{ dBm} &= 100 \text{ mW} \\ 30 \text{ dBm} &= 1 \text{ watt} \end{aligned}$$

$$-30 \text{ dBm} = 1 \text{ microwatt}$$

etc.